

A-Arm – How To Wrap long Loads

Here are some suggestions on how to wrap long rectangular loads on the A-Arm.

- 1) Consult with your Cousins Packaging Regional Manager if one of the load dimensions (L or W) is over 64". The application may require special handling and the optional one (1) ft. base extension.
- 2) Depending on the mix of load sizes, loads larger than 64" x 64" (90" diagonal) may require the operator to place the load on the turntable with the longest side facing the machine tower as shown below. Your Regional Manager will advise the best loading procedure after all load sizes are provided.
- 3) A very large load diagonal may require the film carriage to feed film at a faster rate. The High Speed Film Feed Option may be required.

OHOSP	High Output Speed Prestretch
-------	------------------------------

